



domovari - GLAS lacquered and satin-finished & lacquered

The fronts or shelves are made of ESG safety glass (8 mm) with a rear lacquer coating – available in either clear or satin-finished versions:

DAILY CLEANING

Use a dry microfibre cloth or a soft duster. Regular, gentle wiping prevents scratches caused by dust particles.

DAMP CLEANING

For clear glass fronts:

Moisten a lint-free microfibre cloth with clean water or a mild glass cleaner (alcohol-soluble, ammonia-free). Wipe the surface over a wide area without applying pressure, then wipe again with clean water and polish dry with a soft cloth.

For satin-finished glass fronts:

Use warm water with a drop of mild washing-up liquid or a gentle glass cleaner. The cloth should be only slightly damp. After cleaning, rinse with clean water and dry thoroughly.

STUBBORN STAINS

Limescale marks:

On clear glass, limescale marks can be removed using a mild vinegar–water solution (1:5) – always rinse thoroughly afterwards.

For satin-finished glass, dab the limescale very gently with vinegar, then rinse with clean water and dry.

Grease marks or fingerprints:

For both types of glass, use standard alcohol-free glass cleaners, or in the case of clear glass, mild gall soap. Please note that on satin-finished glass, greasy residues may leave visible shadows.

PLEASE AVOID:

Abrasive sponges, steel wool or harsh cleaners (acidic, alkaline, fluoride-based or silicone cleaners) – these can damage both the glass and the lacquer.

Do not spray glass cleaner directly onto the glass; always apply it to the cloth first. Ensure that no moisture penetrates the edges.

Be gentle when wiping and polishing, as satin-finished glass is sensitive to mechanical stress.

DRYING

Dry the glass surfaces – especially the edges – after cleaning with a lint-free cloth to remove all moisture. This protects both the lacquer coating and the ESG edges.